

CURBSIDE / RIGHT TRAILER LIGHT

INSTALLATION INSTRUCTIONS
INSTRUCCIONES DE INSTALACION
CONSIGNES D' INSTALLATION

READ ALL WARNINGS AND INSTRUCTIONS BEFORE INSTALLATION

WARNING: CONSULT VEHICLE AND TRAILER OWNER'S MANUAL BEFORE INSTALLATION. CHECK FOR SENSORS, WIRES, OR COMPONENTS BEHIND THE MOUNTING SURFACE PRIOR TO INSTALLATION.

INSTALLATION INSTRUCTIONS

1. DISCONNECT VEHICLE POWER SUPPLY.
2. SELECT A SUITABLE LIGHT MOUNTING LOCATION.
3. DRILL TWO ¼" HOLES, 2" APART ON CENTER.
4. MOUNT THE LIGHT ASSEMBLY TO THE TRAILER BODY WITH A WASHER, LOCK WASHER, AND NUT, SO THAT THE SIDE INDICATOR LIGHTS FACE OUTWARD.
5. CONNECT WIRE LEADS TO PROPER VEHICLE CIRCUITS.

GREEN WIRE – RIGHT TURN AND BRAKE LIGHT

BROWN WIRE – TAILLIGHTS

NOTE: FOR PROPER LIGHT FUNCTION A GROUND CONNECTION MUST BE ACHIEVED. THIS LIGHT ASSEMBLY IS GROUNDED THROUGH THE MOUNTING BOLTS.

6. RECONNECT VEHICLE POWER SUPPLY.
7. TEST LIGHTS.

LEA TODAS LAS ADVERTENCIAS E INSTRUCCIONES ANTES DE LA INSTALACIÓN

ADVERTENCIA: CONSULTE EL MANUAL DEL PROPIETARIO DEL VEHÍCULO Y DEL REMOLQUE ANTES DE LA INSTALACIÓN. VERIFIQUE SI HAY SENSORES, CABLES O COMPONENTES DETRÁS DE LA SUPERFICIE DE MONTAJE ANTES DE LA INSTALACIÓN.

INSTRUCCIONES DE INSTALACIÓN

1. DESCONECTE LA FUENTE DE ALIMENTACIÓN DEL VEHÍCULO.
2. ELIJA UNA UBICACIÓN ADECUADA PARA EL MONTAJE DE LA LUZ.
3. TALADRE DOS ORIFICIOS DE ¼", CON 2" DE SEPARACIÓN EN EL CENTRO.
4. MONTE EL ENSAMBLE DE LUZ A LA CARROCERÍA DEL REMOLQUE CON UNA ARANDELA, ARANDELA DE SEGURIDAD Y TUERCA DE MODO QUE LAS LUCES LATERALES DE SEÑALIZACIÓN QUEDEN ORIENTADAS HACIA AFUERA.
5. CONECTE LAS TERMINALES DE ALAMBRE A LOS CIRCUITOS ADECUADOS DEL VEHÍCULO.

ALAMBRE VERDE – VUELTA A LA DERECHA Y LUZ DE FRENOS

ALAMBRE CAFÉ – LUCES TRASERAS

NOTA: PARA UNA FUNCIÓN DE ILUMINACIÓN ADECUADA DEBE HABER UNA BUENA CONEXIÓN A TIERRA. ESTE ENSAMBLE DE LUZ SE CONECTA A TIERRA POR MEDIO DE LOS TORNILLOS DE MONTAJE.

6. VUELVA A CONECTAR LA FUENTE DE ALIMENTACIÓN DEL VEHÍCULO.
7. PRUEBE LAS LUCES.

LISEZ TOUS LES AVERTISSEMENTS ET TOUTES LES INSTRUCTIONS AVANT L'INSTALLATION.

AVERTISSEMENT: CONSULTEZ LE MANUEL DU PROPRIÉTAIRE DU VÉHICULE ET DE LA REMORQUE AVANT L'INSTALLATION. VEILLEZ À CHERCHER LES CAPTEURS, LES CÂBLES OU LES COMPOSANTS DERRIÈRE LA SURFACE DE MONTAGE AVANT L'INSTALLATION.

INSTRUCTIONS POUR L'INSTALLATION

1. DÉBRANCHEZ L'ALIMENTATION ÉLECTRIQUE DU VÉHICULE.
2. CHOISISSEZ UN EMPLACEMENT DE MONTAGE APPROPRIÉ POUR LE FEU.
3. PERCEZ DEUX TROUS DE ¼ PO (6,35 MM), À 2 PO (51 MM) DE DISTANCE AU CENTRE.
4. MONTEZ LE FEU SUR LA CARROSSERIE DE LA REMORQUE À L'AIDE D'UNE RONDELLE, D'UNE RONDELLE DE BLOCAGE ET D'UN ÉCROU, DE MANIÈRE À CE QUE LES FEUX LATÉRAUX SOIENT FACE VERS L'EXTÉRIEUR.
5. CONNECTEZ LES FILS CONDUCTEURS AUX CIRCUITS DE VÉHICULE APPROPRIÉS.

FIL VERT – FEU DE VIRAGE À DROITE ET DE FREINAGE

FIL BRUN – FEUX ARRIÈRE

REMARQUE: UNE CONNEXION À LA TERRE EST REQUISE POUR QUE LES FEUX FONCTIONNENT CORRECTEMENT. CE FEU EST MIS À LA TERRE PAR LES BOULONS DE MONTAGE.

6. REBRANCHEZ L'ALIMENTATION ÉLECTRIQUE DU VÉHICULE.
7. VÉRIFIEZ LE FONCTIONNEMENT DES FEUX.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9216 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT TOWSMART.COM.



Winston Products Company
TOWSMART.COM
WINSTON PRODUCTS, LLC.
30339 Diamond Parkway
Cleveland, OH 44139