

## Installation

1. Trim the cable jacket back about 2 in., being careful not to nick any wires inside.
2. Strip about ½ in. of insulation off each wire.
3. For the phone line connections, attach the four color coded wires from one end of phone line cord to the corresponding color wire terminals on Surface Mount Phone Jack or other device. Loosen the screws (1) on the block and connect each of the color-coded phone wires to the corresponding color wire terminal on the block. For example, connect green to green, yellow to yellow, red to red, and black to black. Retighten the screws (1) to secure the wire connections together.
4. attach the six color coded wires from the phone line cord of the other end of phone line cords to the corresponding color wire terminals on the back of the new wall jack. For example, connect green to green, yellow to yellow, red to red, and black to black. Retighten the screws (1) to secure the wire connections together.
5. Attach the wall plate to the wall using the two screws (AA) located on the back of the wall plate.

