Step 1: Attaching the Wall Mounts



Wall Mounts

Center the Wall Mount over the tub's edge with the closed end toward the ceiling. Place the center of the Wall Mount at your desired rod height (at least 75 inches from the floor for a standard 72" curtain).

Tools you'll need: pencil, tape measure, small flat-head screw driver, phillips-head screw driver



Screw Holes

Mark the top and bottom holes with a pencil. Use a standard Phillips head screwdriver to firmly press the tip of a white anchor into the marked position. Next, with continued pressure, screw the anchor until flush with drywall - not recessed. Insert screws through wall mount and into anchors.

Thank You for Your Rotator Rod Purchase!

Here are your instructions for drywall installation. For mounting on tile/stone/fiberglass without drilling check out our No-Drill Adapters! www.RotatorRod.com

For questions, comments or support call 941-706-2272 CustomerService@RotatorRod.com

Wall Mounts x 2





Rod Reacher provides an easy reach for smooth rod rotation.

Caps x 2
Accent Balls x 2
Pins + o-rings x 4
Rod Inserts +
Rotator Disks x 2



Hardware Packet with 4 screws and 4 anchors



Step 2: Sliding the Rod Together

Align tract on Connector with the dimple in the rod and press together. Then twist in opposite directions until dimples align.



COB

Step 3: Snapping Your Rod in Place

Snap in Rod

Once the Wall Mounts are in position, take the rod you just twisted firmly together, remove the plastic and slide the Cap and Ball out of the way.

Snap the Rotator Disks into place by firmly sliding its center point up the groove on the Wall Mount until it 'clicks' into place. Be sure the arrow on the Rotator Disk points down while snapping into place. Repeat on the other side.

EASY TIP The Rod Inserts slide in and out of the rod on either side to adjust the length of the Rotator Rod to fit your bathroom walls.



Step 4: Securing the Ball and Cap



Accent Balls

Slide each Accent Ball to the end of the rod so the arrow on the Rotator Disk is ponting in the direction of the Set Screw in the indent of the Accent Ball. That is, toward the **inside curve** of the rod. There are grooves inside the Accent Ball allowing it to slide over the Rod Pins and snuggle up to the Wall Mounts. Tighten the clear Set Screw in the top of the Ball using a small flat-head screw driver.

Caps

Finally, slide each Cap over its end of the rod against the wall and twist until it locks into the Wall Mount

> COB Products

* NOTE: If, for any reason you wish to remove your Rotator Rod simply insert a flat-head screw driver between the Rotator Disk and the Wall Mount and give it a twist. It will pop right out!