

# Installation Guide for Wood Pyramid and Traditional Pyramid Post Cap

## Step #1: Apply Glue to Post

Place a generous amount of **Liquid Nail** or similar outdoor glue on top of the Post **in the shape of an "S"**. Make sure it is thick enough to spread out once you place the Post Cap on top of the Post.

## Step #2: Mount Post Cap to Post

Place the **Post Cap** on top of the Post where the glue has been applied. Move the cap around to completely spread the glue.

**\*\*DO NOT PUSH TOO HARD OR THE GLUE WILL FLATTEN TOO MUCH**

Make sure the Post Cap is sitting the way you want on top of the Post.

## FAQ

**Q: Can I screw the wood cap from the top right into the post?**

A: We do not recommend screwing the post cap into the post from the top. If you decide to do this, pre-drill a hole to prevent cracking.

**Q: Can I screw from the side of the wood base into the post?**

A: If you decide to do this, you should pre-drill holes in the wood cap to avoid splitting.

**Q: Can the wood caps be left alone or do they need to be protected with some "sealer"?**

A: Since the wood caps are Mahogany they can be left alone to weather to a gray color. If you want to preserve the "new" look then choose a coating that gives you the protection you desire. You can also paint or stain the wood caps.

Detail shown for  
Traditional Pyramid.  
Mount Wood Pyramid  
in same fashion

