

INSTALLATION GUIDE FOR POLY SHEETING



- Poly Sheeting may be installed vertically
- Scaffold wind clips, bungees ties, tie wire, wood furring strips can be used, or fastening directly to a building or structure.