



INSTALLING WALL ANCHORS & MOUNTING HOOKS FOR WALL DECOR

Determine if there are wooden wall studs directly behind the anchor mounting marks. You can do this with a stud finder purchased from a hardware store, or by drilling a small pilot hole. If the drill bit hits wood, you've found a wall stud. If it hits nothing and goes straight through, there is no stud and you'll need to use a wall anchor/shield.

For walls with wooden studs directly behind the anchor points, simply drill two small pilot holes into the wall at the anchor points and use the screws provided to hang your mirror.

For mounting areas without wood studs directly behind the anchor marks, you'll need to use wall anchors/shields to secure the screws to the wall. Drill a hole in the wall at each anchor mark and then push the wall anchor/shield into this hole. Now simply screw the mounting screws into the wall.

After installing your screws, place the wire on the back of the mirror frame onto your screws (leave screws extended approx. 1/8 inch from the wall) and step back to visually inspect the placement of your mirror.