

AIR CONDITIONER DRIP CUSHION

Magnetic/Foam

Preparation:

Make sure the top of the air conditioner is clean and dry.

Installation:

1. Measure the exposed top of the air conditioner. If necessary, cut to size with scissors or a blade.
2. Using a piece of paper or cardboard as a tray, slide the cushion in place, foam side up.
4. Slide the paper or cardboard out from under the cushion.
5. Make sure the cushion does not extend over the edges of the air conditioner, to prevent it from blowing off.



Magnético/Espuma COJÍN DE GOTEÓ PARA ACONDICIONADOR DE AIRE

Preparación:

Asegurese que el tope del acondicionador esté limpio y seco.

Instalación:

1. Mida el tope expuesto del acondicionador de aire. De ser necesario, corte el cojín con tijeras o una navaja.
2. Usando un pedazo de papel o cartón como bandeja, coloque el cojín en su lugar, con el lado de espuma hacia arriba.
4. Quite el papel o cartón de debajo del cojín.
5. Asegurese que el cojín no extienda sobre el borde del acondicionador, para prevenir que no lo sople el viento.

Tools Needed
Se Requiere Herramienta



Follow Us @FrostKing
or www.frostking.com



Thermwell Products Co., Inc.
Mahwah NJ 07430 | Sparks NV 89431

Need help or information
about any Frost King product?
Call **1-877-FROST 20**
3 7 6 7 8

For videos, instructions, hints and tips
visit www.frostking.com/instructions