

# R128-2

## INSTRUCTIONS:

1. Slide flange over nipple to cover rough opening in wall. Internal fingers of flange pinch together to insure tight fit.
2. Place a thin bead of silicone around back of flange.
3. Cover wrench pads on shut-off valve and compression nut with tape to protect finish.
4. Tighten valve onto nut using two wrenches.

## INSTRUCCIONES:

1. Insertar la brida sobre la unión para tapar la abertura en la pared. Las pestañas internas de la brida se ajustan solas para asegurar un buen encastre.
2. Coloque cordón delgado de silicona alrededor de escudo.
3. Cubrir almohadillas llave en la válvula de cierre y la tuerca de compresión con cinta adhesiva para proteger el acabado.
4. Apriete la tuerca de la válvula en el uso de dos llaves.

