



INSTRUCTIONS FOR USE

INSTRUCCIONES DE USO

DOOR SWEEP

Self Stick

Preparation:

Install when the temperature is between 40° - 90°F (5°-32°C).

Installation:

1. Make sure the door surface is clean, dry and grease-free.
2. Measure door width.
3. Shorten sweep if needed.
4. Place the product so the sweep flexes against the threshold.
5. Remove the backing paper and press sweep into place.

Autoadhesivo

GUARDAPOLVO PARA PUERTA

Preparación:

Instale cuando la temperatura esté entre 40° - 90°F (5°-32°C).

Instalación:

1. Asegúrese que la superficie esté limpia, seca y libre de grasa.
2. Mida el ancho de la puerta.
3. Corte el guardapolvo si es necesario.
4. Coloque el producto de manera que la escobilla flexione contra el umbral.
5. Quite el papel de reverso y presione la tira en su lugar.

TOOLS NEEDED:

HERRAMIENTAS NECESARIAS:



Follow Us @FrostKing
or www.frostking.com



Thermwell Products Co., Inc.
Mahwah NJ 07430 | Sparks NV 89431

Need help or information
about any Frost King product?

Call **1-877-FROST 20**
3 7 6 7 8

For videos, instructions, hints and tips
visit www.frostking.com/instructions