



SimpleSolutions Moisturebloc is a 6-mil virgin polyethylene film for use on concrete slabs to protect against moisture.

### **Installation Steps**

1. Follow the flooring manufacturers' installation instructions regarding site preparation and leveling the subfloor. Make sure the subfloor is level, clean, dry and secure.
2. Unroll the Moisturebloc polyethylene film. Cut the film about 2 inches longer than the room length on each end. Run the film 2 inches up on each wall. This 2 inch perimeter running up the walls provides a moisture-proof enclosure for the flooring.
3. If needed, lay a second row of film alongside the first with overlapped seams of 8" or more.
4. After the flooring is completely installed, trim the excess film back to the height of the finished floor. Do this prior to installing base boards or molding.