

# ColourTree



## Artificial Turf Installation Guide

### 1. Preparing the Area

- Remove at least 2 inches of your existing lawn/base

### 2. Creating a Base

- Evenly spread 4 inches of road base for a level foundation with proper drainage. Wet the area and flatten with a compactor

### 3. Laying out Turf

- Roll out your ColourTree artificial turf and let it sit for an hour for it to unfurl

### 4. Cutting to Size

- With your turf on the desired area, you may cutting to fit your area perfectly. Cut from the back and leave 1/4" to 1/2" of turf extra when cutting for the next step

### 5. Securing the Turf

- Tuck the 1/4" to 1/2" edge into the border with a putty knife and hammer and drive your staples into the ground every 6 inches along the perimeter and every 2 feet inside the area

### 6. Applying Filler

- Brush up the turf to keep the blade memory vertical before spreading infill. Using a drop spreader, use one or a mixture of: Zeolite, Crumb Rubber, Silica Sand, and Acrylic Coated Sand

### 7. Final Groom

- a) Complete one final brush up with a stiff-bristle broom or power broom