

Installation Manual

Product: Stainless Steel Corner Bathroom Shelf

Brand: HOMEMYSTIQUE

Package Contents

- 1 × Stainless Steel Corner Shelf
- 4 × Screws
- 4 × Wall Anchors
- 1 × Installation Manual

Tools Required (Not Included)

- Electric Drill
- Screwdriver
- Measuring Tape
- Level (Recommended)

Installation Steps

Select Mounting Location

Choose a clean and dry corner on your bathroom wall.

Recommended height: Lower shelf ~90-100 cm (35-40 in) from the floor, Upper shelf ~25-30 cm (10-12 in) above lower.

Mark Drilling Points

Hold the shelf against the wall.

Mark the positions of all 4 screw holes (2 for each tier).

Drill Holes

Use a 6mm (1/4 inch) drill bit to drill holes at marked positions.

Insert Wall Anchors

Push wall anchors into the drilled holes until flush with the wall surface.

Mount the Shelf

Align the shelf with the anchor holes.

Secure it using the screws provided.

Final Check

Ensure the shelf is firmly attached and level.

Test stability with light pressure.