

Installation instructions

1. Apply glue on the back and stick it at the desired location
2. Use double-sided self-adhesive glue to fix
3. Fix with nail gun