

Installation for Tin Sign

Materials Needed:

- Wall Space
- Tin Sign
- Hammer
- Pencil
- Nail
- Stud Finder (optional)

Find the perfect spot to hang your tin sign (using a stud finder is optional), hold the sign against the wall in that spot. Using the pencil, mark above the sign. Make sure when you mark it is directly above the sign to minimize the chance of the sign hanging askew. Using the hammer, put the nail into the wall on the mark you made. You want to make sure that you do not hammer the nail all the way into the wall so the sign will have space on the nail to hang onto. Now that your nail is secure in the wall, you are ready to hang your sign!