

DC 181 HVAC Flex Duct Tape Usage Instructions

Typical Applications:

- For use on Class 1 Flex Duct for connecting, joining, sealing and patching flexible air ductwork.
- Can be used in temperatures ranging from -10 F to 210 F.

Proper Installation:

The proper installation of DC 181 HVAC Flex Duct Tape ensures the tape will perform as designed:

- The surface the tape is adhered to should be clean and dry.
- The tape should be unwound and placed in position on the ductwork.
- Once the tape is in place, proper pressure must be applied for the adhesive to achieve a permanent bond. A squeegee should be used to ensure the pressure is applied across the entire width of the tape.
- Once this has been completed, the tape is considered installed properly.