



## Rave Roof Pad Rack System

Vendor part number 02499

SKU 38391257

For Automobiles with no roof rack or with cross bars wider than 2". For Autos w/ >2" wide cross bars, follow procedure for #02500 roof pads.



1. Lay pads across top of car roof w/ flat side down.



2. Place paddle board face down toward windshield.



3. Holding onto buckle end, toss loose end over the top of the board. Put 3-4 twists in strap and feed back across inside of car through both windows or doors.



4. Ensure padded side of buckle lies on the edge of the board. Ensure metal part of buckle cannot contact board & cause damage.



5. Pull snug (not tight at this point).

(Repeat steps 3 - 5 on second straps)



6. After both straps are snugged up, pull both tight so there is even tension on both front and back straps. Do Not Overtighten.



7. Tie knot with the remaining loose strap (very close to the buckle to keep strap from slipping in buckle). Tie/wrap remaining strap to roof rack or pinch in window to prevent flapping in the wind.