



Camper Seal Foam Tape

Easy to Use:

(Leave paper liner on foam during installation)

1. Be sure application surface is clean and dry. Temperature should be above 40°F (5°C).
2. Apply tape to bottom of camper shell as tape is unrolled. Do not stretch tape during installation.
3. Remove paper liner.
4. Set camper in place.