

Wall Corner Cabinet installation instructions

Tool preparation:

Electric drill

Screwdriver

Level

Tape measure

Screws and expansion bolts

Installation bracket (if any)

Installation steps:

Measure and mark the installation position

Use a tape measure and a level to measure the installation height and width of the corner. Mark the position of the cabinet top and the fixing holes to ensure horizontal alignment.

Installation bracket (if applicable)

If you use a mounting bracket, use an electric drill to drill holes at the marked position, install the expansion bolts and fix the bracket to the wall.

Fix the hanging plate

Fix the hanging plate (if any) on the back of the wall cabinet to the corresponding position on the wall to ensure that it fits the wall firmly.

Hanging the cabinet

Two people work together to lift the cabinet and hang it on the installed hanging plate or bracket. If the cabinet is not completely aligned, please fine-tune the position.

Fix with reinforcement screws

Open the cabinet door and use screws on the inside of the cabinet to further reinforce the cabinet and the wall to ensure safety and stability.

Check the level and adjust

Use a level ruler to confirm whether the cabinet is level again. If fine-tuning is required, loosen the screws and re-adjust the position before tightening.

Notes:

Make sure the wall is solid (such as cement wall, brick wall); it is recommended to add a wooden backboard to the gypsum board wall to enhance the load-bearing capacity.

Before installation, please check whether all parts are complete.

Please wear protective tools during installation to ensure safety.