Limited Warranty: Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems as follows; this warranty is in lieu of all other written or unwritten, expressed or implied warranties, and Tub Refinishing, Inc. DBA Munro Products or Munro Bath Systems expressly disclaims any warranty of merchantability or fitness for a particular purpose. The buyer assumes all risks whatsoever as to the use of the material. Keep away from children, animals, or persons that are sensitive to paint or fumes. Fumes can be harmful to humans and animals, and can also be flammable.

Safety: A protective respirator can be worn if available. Use product with adequate ventilation. Always use rubber gloves.

Tub Refinishing, Inc., DBA Munro Products or Munro Bath Systems, is not responsible for accidents or misuse of these products or parts and materials of this kit. Safety is in the hands of the user. If you are unsure about the use or safety of this product please return the unopened and unused kits to the supplier. Do not return goods without receiving a Return Materials Authorization (RMA) number from Munro Products. All returned goods are at the purchasers cost. Opened or used materials will be refused for credit. See all MSDS Sheets which are provided and are also available via our websites. http://www.bathtubrefinishingkit.net

Suitability for use: The user is responsible for establishing that these products are suitable for the user's application and that all requirements for meeting approvals, standards, codes, disposal, use and regulations of any kind are satisfied. Distributor denies any responsibility for establishing suitability of use; where, when, and how the materials from this kit are used. Read all information and instruction before use of this product. Use Caution!

For Emergency: CHEMTREC® 1-800-424-9300

Tub Refinishing, Inc. DBA Munro Products, Munro Bath Systems, and BathWorks™. BathWorks™ is an exclusive trademark of this company.

BATHWCRKS

Tub, Tile, Wall Surround, & Sink Refinishing Kit

Preval Kit - Instruction Manual

Step 1: Clear the area of all personal items. Make sure there is positive air-flow as well as good ventilation on work areas at all times.

Step 2: Make sure desired spray area is sanded and wiped of all debris.

Step 3: Pour desired amount of Part A into the jar then add Part B and the solvent included with the kit.

* **NOTE:** The mixing Ratio is 3 parts Base (part A) to 1 part Hardener (part B) to 1 part Solvent.

Step 4: Replace the cap and mix thoroughly.

Step 5: Remove the cap from the jar and attach the Power Unit to the Jar. Test spray before beginning.

* **NOTE:** Add more solvent if a finer spray is needed – Read Spray Unit for additional Instructions.

Supplies Included in Kit:

• Completely portable spray gun comes with refillable jar, Preval power unit, and reducer.

For Recommended Tools & Supplies Visit:

http://www.bathtubrefinishingkit.net/Category/Accessories