

Instructions:

1. Place number in desired location and mark screw locations.
2. Drill 1/16 in pilot holes.
3. Secure number with included screws.

Note:

Clean only with a soft cloth, mild soap and water.

Do not use abrasive polishes or cleaners.