

**Step 1: Pre-Installation**

- Remove existing materials.
- Cap sprinklers, if necessary, relocate sprinklers, modify existing irrigation lines, and add any required drainage
- If necessary, Install Bender Board

**Step 2: Base Preparation**

- Properly distribute and level base

**Step 3: Compact the Base****Step 4: Custom Fitting**

- Place the grass on prepared area. When trimming to fit the area properly you should over cut the turf by one inch along the edges. This provides the excess turf necessary for tucking.

**Step 5: Tuck the Edges****Step 6: If necessary, secure the perimeter.**