

Method of Application:

SURFACE PREPARATION: New surfaces: Must be clean and dry, free of grease, oil or dust. Sand the wood in the same direction as the grain. Start with a medium grain sandpaper(#120) and then change to fine grain sandpaper (#220). Remove all dust from the wood with a clean dry cloth. Previously painted wood: Remove all stamping or paint completely. Use Lanco Safe Strip for indoor or outdoor use (Read the instruction on label before use). If after this step the wood still has residues from previous ones, use a wood bleach to remove the old color.

APPLICATION: Stir gently before and during the application of Lanco Aquavar 3-1, taking care not to add air to the product, or it would form bubbles in its final layer. Apply the first coat with a good quality brush, always in the direction of the grain of the wood. Let it dry for 4 hours and apply a second coat, always in the direction of the grain of the wood. Do not brush once the product begins to dry and always keep the edges wet. Intense colors may require more layers.

NOTE: Before beginning to paint, look for a hidden place in the object to be treated, and try a small area to confirm that the color is the desired one.

FINAL FINISH: The final layer will be ready to use in 24 hours after its application.

DANGER/WARNING:

CAUTION: Harmful if swallowed. Contains urethane and acrylic resins. In case of eye contact, flush thoroughly with water. Do not rub eyes. In case of skin contact, flush area immediately with clean water. If swallowed, do not induce vomiting. Consult a physician immediately. Use only with adequate ventilation. Goggles are recommended while handling the product. **KEEP OUT OF THE REACH OF CHILDREN.**

Notice: The technical data contained herein are true and accurate to the best of our knowledge. Published technical data and instructions are subject to change without prior notice.

S.D.S. : Available upon request.

