

Fence Installation Instructions

Overview

This manual provides step-by-step guidance for assembling and installing the metal fence panel with the matching privacy screen. Follow these steps to ensure a sturdy, secure setup for your outdoor space.

Step 1: Unpack & Prepare

1. Lay all metal fence panels, connecting parts, privacy screen, and zip ties on a flat, clean surface.
2. Inspect all components for damage (e.g., bent metal, missing holes). Contact customer service if any parts are defective.
3. Put on protective gloves to avoid scratches during installation.

Step 2: Assemble the Metal Fence Frame

1. ****Connect Panels****: Take two fence panels and align the vertical posts. Insert the connecting tube into the top/bottom of the adjacent posts (refer to “Simple to Connect” diagram) – this locks the panels together securely.
2. ****Extend the Frame****: Repeat Step 2.1 to connect additional panels until you reach your desired fence length. Ensure all connections are fully inserted for stability.
3. ****Adjust Stakes****: Confirm the pointed stakes at the bottom of the posts are straight (refer to “Simple to Use” diagram) – these will anchor the fence to the ground.

Step 3: Install the Fence Frame to the Ground

1. ****Mark the Layout****: Use a tape measure to mark the fence’s position on the ground, ensuring it’s straight.
2. ****Anchor the Fence****: Starting with the first panel, position the pointed stakes on the marked spot. Gently tap the top of the posts with a rubber mallet to drive the stakes into the ground.
3. ****Level the Panels****: As you drive each post, use a level to check that the panel is vertical (no leaning). Adjust the stake depth as needed to keep the fence straight.
4. ****Secure All Panels****: Continue tapping each post into the ground until all assembled panels are firmly anchored.

Step 4: Attach the Privacy Screen

1. ****Position the Screen****: Unroll the green privacy screen over the assembled metal fence frame. Align the screen’s edges with the fence’s top/bottom and sides for full coverage.
2. ****Fasten with Zip Ties****: Use the included zip ties to attach the screen to the fence:
 - Start with the corners: Thread a zip tie through a grommet (metal eyelet) on the screen and around a fence rail, then tighten to secure.
 - Space zip ties 6–12 inches apart along the top, bottom, and sides of the screen. Add extra zip ties in the middle of the screen (vertically/horizontally) for added stability (especially in windy areas).
3. ****Trim Excess****: Once all zip ties are tightened, use scissors to trim off the excess plastic tails for a clean finish.

Step 5: Final Check

1. Walk along the entire fence to ensure all panels are securely connected, stakes are fully anchored, and the privacy screen is taut (no sagging).
2. Test stability by gently pushing the fence – it should not shift or lean. If loose, re-tap the stakes or add extra zip ties to the screen.