



Coverage: 124-200 sq. ft • 16 fl. oz./474 ml

Variation in coverage is due to flooring type (laminate, wood, click or T&G), size (thickness, length & width), and application methods.

Limited Warranty:

Cal-Flor warrants that this product will be free from manufacturing defects for 12 months from the date of purchase, when applied in accordance with Cal-Flor's instructions and industry standards. Cal-Flor's sole liability is to either supply new product or refund the original purchase price. This limited warranty excludes all other express warranties including the warranties of merchantability for a particular use or purpose. Cal-Flor will not be liable for any incidental or consequential damages.

The SDS can be found by visiting www.cal-flor.com

Installation Guide

EUROBOND D3/Type II FLOATING FLOOR GLUE

Directions

For use on laminate or wood floating floor systems.

LAMINATE: Trim tip opening to 1/16" • **WOOD:** Trim tip opening to 1/8"

1. Follow your flooring manufacturer's instructions for adhesive application.
2. Squeeze a continuous bead of glue onto the top side of the tongue. Glue must be applied to entire length of seam.
3. For added strength, squeeze a continuous bead of glue onto the bottom of the groove. This will reduce the chance of gapping over the life of the floor. **DO NOT** fill in groove as this may result in gapping during installation.
4. *Assemble planks before glue skins over.* For maximum moisture protection, make sure glue squeezes out of the joint continuously along the length of all seams.
5. Allow 10-15 minutes for excess glue to set up.
6. Using a plastic putty knife, remove excess glue and wipe seam with a lightly damp cloth. Keep cloth clean to avoid smearing glue.
7. Allow to dry for 24 hours before walking on floor. Allow 2-3 days before installing heavy furniture or appliances.
8. *Clean Up after 24 hours:* For removing installation glue drips and smears that have dried or cured, use our FilmFree Advanced Cleaning Formula & Adhesive Remover.