

BLACKOUT LINER PANEL • EASY INSTALL GUIDE

47" IN X 80" IN • Easy to Install with all types of draperies

As a liner for STANDARD ROD POCKET DRAPES

1. Package contains one 47" wide panel liner that is intended to hang flat or with gathering behind your curtain panel.
2. Place the liner on a separate rod.
SEE PICTURE A.
3. Hang the liner, then hang the curtain.
SEE PICTURE B.
4. Purchase additional blackout liners as needed. (covering windows wider than 47")



PICTURE A



PICTURE B

As a liner for PINCH PLEATED DRAPES

1. Package contains one 47" wide panel liner that is intended to be attached flat or with some fullness to the back of a 47" pinch pleated curtain panel.
2. Place curtain without rod, face down on a flat surface.
3. Position blackout liner over the curtain panel.
4. Start on the outside and work toward the center. Loop the liner braid over the curtain hooks as shown. The liner braid must be facing the hooks.
5. Carefully work loops toward the bottom of each hook.
6. Proceed to hang the curtain with the liner in place.
7. Hook the included extra pin hook into the first loop of the braid on the right side of the panel.
8. Hook the pin to the carrier on the curtain rod.

colordrift

©Colordrift LLC, 2018, 110 York St., Brooklyn, NY 11201 RN136432

As a liner for GROMMET OR TAB TOP DRAPES

1. Package contains one 47" wide panel liner that is intended to be attached flat.
2. Place curtain without rod, face down on a flat surface. Position blackout liner over the curtain panel.
3. Insert included pin hooks into the curtain at evenly spaced points. **SEE PICTURE C.**
4. Loop the liner braid over the curtain hooks as shown. **SEE PICTURE D.**
5. Hang curtain with new liner in place.



PICTURE C



PICTURE D