



WG
Wood Products

2022 Installation Instructions for ON-the wall Spice Racks

Tools Needed:	Stud Finder, Tape Measure, Pencil, Hammer, drill, 1/8" drill bit or awl, Phillips Screwdriver, Phillips Tip, Level
01	Depending on the product ordered, your rack may be unfinished, primed or already pre-finished in a color. If your rack is unfinished or primed, paint or stain the rack as desired. You can remove the mounting brackets and put them in a safe place while you are finishing the rack. Depending on mounting method, you may not use all of the hardware we have provided.
02	The mounting brackets (See figure A) have already been placed inside the rack for you. And the back panel has already been drilled and mounted in place with framing tabs that bend over to secure it. If you need to remove it, simply bend the tabs back and pull the panel out. Be sure to put it back in the proper orientation so that it lines up with the holes in the mounting brackets.
03	Determine the placement on the wall or door and mark the location of the mounting brackets on the wall surface. Check to see where studs are in your wall. If your locations match up, great. If not, you can use the included wall anchors instead. If you are mounting on a hollow core door, go to step 5.
04	Set the spice rack aside and using a 9/32" drill bit or awl, drill/puncture a hole in the position where you marked for the bracket to mount. This way your anchor will not wander when started. If your drill bit hits a stud, that's great, you won't need a drywall anchor for this location. If not, that's OK too – just use a drywall anchor in that position. Take the plastic drywall anchors provided and screw them into the drywall until it is flush. Do not over screw it. It just needs to be flush with the wall to be secure. See Figure B. Using the 2" drywall screws hold your spice rack in the position of the anchors and tighten one at a time until spice rack is secured to the wall.
05	HOLLOW CORE DOORS ONLY: Place the spice rack in the desired location and mark the mounting holes on the door, just like above. A second set of hands holding the rack while you mark your locations will be very helpful. NOTE: This needs to be on a flat surface to work properly. If your door has raised panels molded into it, you may need to change the location of the mounting plates so that each one is on a flat surface of the door panel. Now set the rack aside.
06	Once you mark the door where you want the spice rack to go, using a drill and a 1/4" drill bit, drill the locations marked for the expansion anchors. Install the anchor bodies into position by screwing them in until they are flush. Now tighten the screw all the way down to snug them. The act of tightening the screw causes the expansion anchor to mushroom behind the panel and secures it so that it cannot come back out. See Figure C.
07	Now unscrew the bolt from the expansion anchors (they are now locked in place and can't come out) and place the spice rack in position and feed the bolt thru the new mounting brackets and screw it back into the expansion anchors until snug using a hand screwdriver. We recommend that you do not mount any spice rack taller than 48" or deeper than 4.5" on a Hollow Core Door!!




**Mounting
Brackets
Already
Installed**

Figure A.

*Depending on
model,
mounting
brackets may
be either
metal or
plastic.*



**Screw in wall using
phillip screwdrivers**



Screw in flush to wall

Figure B.



Figure C.



All of our Spice Rack models have multiple optional accessories you can order including different dowels (wood, acrylic, or aluminum), top and bottom trims, and over 30 different styles of doors. All doors come with concealed hinges with soft close built in.

You can get information and purchase optional accessories or replacement parts by calling **931-829-6000** or by emailing:
info@timbertreecabinets.com

Still have questions or need help?



Installation videos are on our website:

WGWoodProducts.com

Enter the link into your browser:

https://www.wgwoodproducts.com/store/agora.cgi?cartlink=Installation_Videos.htm



Or you can call us at 913-829-6000