

Undermount Kitchen Sink Installation Instruction

This sink is specifically designed to be under-mounted in a solid surface countertop only.

CAUTION: Sink edge may be sharp; handle with caution. Do not install a damaged sink – inspect carefully.

1. Cut out countertop using this template.
2. Determine placement of clip brackets as indicated by template. Pre-drill holes according to method desired based on countertop material.
3. Apply a bead of silicon evenly along edge on underside of countertop.
4. Position and align sink over opening. Press sink onto silicon seal.
5. After re-checking alignment, tighten clip brackets against sink edge.
6. Remove excess silicon

NOTE: THIS TEMPLATE IS ONLY A GUIDE. ACTUAL SINK SHOULD BE PRESENT TO ENSURE PERFECT CUT OUT.

HINT: After silicon cures, wipe inside edge with denatured alcohol. This will smooth out any rough areas.

