

WINDOW AIR CONDITIONER SIDE INSULATION PANELS

Urethane Foam

Installation:

1. Remove the existing side panels, leaving the frame.
2. Measure the height of the air conditioner.
3. Cut the foam panel and the plastic channel to the proper height.
4. Slide the uncovered edge of the panels into the frame.
5. Remove the protective strip from the plastic channel and press it firmly against the side of the air conditioner.
6. For additional insulation, install the panels on top of the existing panels.



Espuma de Uretano

PANELES DE AISLAMIENTO LATERALES PARA ACONDICIONADOR DE AIRE

Instalación:

1. Quite los paneles existentes, dejando el marco.
2. Mida la altura del acondicionador de aire.
3. Corte el panel de espuma y el canal plástico a la medida adecuada.
4. Deslice la orilla llana en el marco.
5. Remueva la tira protectora del canal plástico y presiónelo firmemente contra el lado del acondicionador de aire.
6. Para aislamiento adicional, instale los paneles de espuma encima de los paneles existentes.



Follow Us @FrostKing
or www.frostking.com



Thermwell Products Co., Inc.
Mahwah NJ 07430 | Sparks NV 89431

Need help or information
about any Frost King product?
Call **1-877-FROST 20**
3 7 6 7 8

For videos, instructions, hints and tips
visit www.frostking.com/instructions