



From Power Source:

1. White connects to the white wire from the motor.
2. Black connects to one of the black leads on the T-stat and one of the black leads of the H-Stat. (As Shown)
3. Green connects to the green ground screw on the PT6 and H1 casings.

From Fan Motor:

4. Black (w/ White Stripe) goes to the remaining black leads of the t-stat and the H-stat. (Ensure connections are as shown)

NOTE: Follow all Electrical Codes when installing. Remove power from the circuit before connecting wires.