



INSTALLATION INSTRUCTIONS FOR INTERIOR PREHUNG DOORS

TOOL REQUIRED:

- Hammer
- 4 Feet Level
- 2-inch finish nails
- Wood or plastic shims
- Hand Saw
- Construction knife
- Measurement Tape
- Pencil

BEFORE YOU START INSTALLATION CHECK YOUR ROUGH OPENING

| Door Size | Overall Dimensions | | Rough Opening (R.O.) | |
|-------------------|--------------------|------|----------------------|---------|
| | Width | High | Width | High |
| 18" | 19 1/2" | 82" | 20" | 82 1/2" |
| 22" | 23 1/2" | 82" | 24" | 82 1/2" |
| 24" | 25 1/2" | 82" | 26" | 82 1/2" |
| 28" | 29 1/2" | 82" | 30" | 82 1/2" |
| 30" | 31 1/2" | 82" | 32" | 82 1/2" |
| 32" | 33 1/2" | 82" | 34" | 82 1/2" |
| 36" | 37 1/2" | 82" | 38" | 82 1/2" |
| 36" (Double Door) | 37 3/4" | 82" | 38 1/4" | 82 1/2" |
| 44" (Double Door) | 45 3/4" | 82" | 46 1/4" | 82 1/2" |
| 48" (Double Door) | 49 3/4" | 82" | 50 1/4" | 82 1/2" |
| 56" (Double Door) | 57 3/4" | 82" | 58 1/4" | 82 1/2" |
| 60" (Double Door) | 61 3/4" | 82" | 62 1/4" | 82 1/2" |
| 64" (Double Door) | 65 3/4" | 82" | 66 1/4" | 82 1/2" |
| 72" (Double Door) | 73 3/4" | 82" | 74 1/4" | 82 1/2" |

PRE-HUNG DOOR INSTALLATION IN A FEW EASY STEPS (SINGLE DOOR)

STEP 1

Remove the plastic pin that holds doors closed

STEP 2

Using the level, check if the opening is straight

STEP 3

Double-check door swing. When the door opens to you and hinges on the left side, the hole for the door knob on the right side is a **Right-Hand door**. When you see hinges on the right side of the door and the hole for the knob on the left side, it is a **Left-hand door**

STEP 4

Lift the door to the opening bottom first, and you need to handle the door from the side where you see the hinges, Check with the level side of the jamb with hinges is straight

STEP 5

Install shims to opposite hinges side and top of the door, check with the level if it is straight, and make adjustments with shims

STEP 6

After you finish the adjustment, put two nails thru the jamb on each place where you installed the shims

STEP 7

Countersink all nails, Paint, if desired, **don't sand the door and door jamb**; it is 100% ready to be Paint, and install the door knob

STEP 8

Enjoy every time when you open and close your new solid, heavy-duty interior door



PRE-HUNG DOOR INSTALLATION IN A FEW EASY STEPS (DOUBLE DOOR, FRENCH DOOR)

NOTE: THE DOUBLE DOOR (FRENCH DOOR) COMES PRE-HUNG BUT DISASSEMBLED BECAUSE OF THE DOOR'S WEIGHT AND DIMENSIONS AND FOR A BETTER INSTALLATION EXPERIENCE. DOOR SLABS DON'T HAVE PREDRILLED HOLES FOR THE KNOB. TOO MANY VARIATIONS ON HOW THIS DOOR CAN BE USED PREVENT BAD EXPERIENCES, CUSTOMERS DECIDING HOW TO INSTALL KNOBS ON THE SIDE.

STEP 1

Open the bag with screws, it attached to the door jamb

STEP 2

Combine the sides of the door jamb together using 1-inch black screws (phillips) from the bag. Hinges on both sides of door jambs should be on one side. To install the top correctly stopper on the door jamb and top should be in one line without offset

STEP 3

Unscrew hinges for the jamb of the door

STEP 4

Using the level, check if the opening is straight

STEP 5

Install the door jambs to the opening, nail two nails through the jamb, and shim to the opening. Use for nails places routed for hinges

STEP 6

Attach the door slabs to the installed door jambs

STEP 7

Make necessary adjustments until the door close smoothly

STEP 8

The doors have installed catch ball. After you finish adjustment, you need to install on the top of door jamb plates for catch balls, using plates and screws from the bag



STEP 9

Paint, if desired, **don't sand the door and door jamb**; it is 100% ready to be Paint, and install the door knob

STEP 10

Enjoy every time when you open and close your new solid, heavy-duty interior door