

INSTALL TIPS AND TRICKS



Place each post in a hole that's at least 3x width of post.

*always call 811 before digging.



Position top rail 6" from top of fence and bottom rail 6" from bottom. Place third rail in between.



Maintain 2" of ground clearance to prevent rot and insect infestation.



Use two fasteners to attach pickets to each rail.



For added finish and protection, include trim at the top and bottom.



Stain your fence to enhance its natural beauty.