

Curtain Holdback/Tie Back Installation Instruction



1. Measure out where the J-Hook is to be installed, remember that J Hooks are installed horizontally with the long end flush against the wall
2. Use a drill to create holes for the hooks
3. Screw in supplied screws to mount the J-Hooks in place
4. Attach the finials to the short end of the J-Hook, some finials can attach by themselves, other require a plastic finial insert that will be included