# Installation:

1. Measure door width.
2. Shorten sweep if needed.
3. Place the product so the sweep flexes against the threshold.
4. Mark hole locations, then drill and screw into place.

***Guarantee:***

*If this product loses its weathersealing ability under normal use within your lifetime, Frost King will replace it or refund the price to the original puchaser upon proof of purchase.*

# Instalación:

1. Mida el ancho de la puerta.
2. Corte el zócalo si es necesario.
3. Coloque el producto de manera que el burlete flexione contra el umbral.
4. Marque los agujeros, taladre y atornille en su lugar.

***Garantía:***

*Si este producto pierde la capacidad de proteger contra mal tiempo durante su vida, Frost King le reemplazará o devolverá el precio al comprador original con prueba de compra.*

**A79/36**
**Silver**

**Thermwell Products Co., Inc.**
Mahwah NJ 07430 Sparks NV 89431