

Corten Steel Landscape Edging Instructions

Parts Check

Unpack 6 packs of edging to confirm each piece is 40" L x 8" W, including 2.4" spikes. Total length after installation: 20 feet.

Preparation

Clear the installation area of weeds and debris. Plan your desired shape (curved or straight) for garden beds, paths, or borders.

Installation Steps

- . Position the first edging piece with the 5.6" above-ground section facing up.
- . Use your foot to firmly press the 2.4" spikes into the ground until the edging is stable.
- . Connect the next piece: Align the steel buckle of the second edging with the first piece's buckle. Press to lock tightly—no tools needed.
- . Repeat to join all 6 pieces, forming a 20-foot edge.