

Our bathtubs come with a pop up drain already installed and overflow already integrated to the drain. The preferred method would be to attach bottom of drain to your floor drain with rigid plumbing. The flexible drain hose is an optional piece only to be used if you have no access underneath the bathtub. One end screws onto the bottom of the bathtub drain and the on the other end to your floor drain using a transition piece, compression fitting, or clamping fitting you can get from any Home Improvement store. Hope this helps. Have a great day.