



Alpine Industries
27 Selvage St.
Irvington, NJ 07111
Tel: 973 601 5105
Fax: 973 854 8650

Stainless Steel C-fold/Multi Fold Towel Dispenser

Item# 480, 480-AB, 480-AC, 480-AN, 480-ARG, 480-COP

Installation

1. Please choose a vertical, clean and smooth mounting surface.
2. Make sure there is enough room above dispenser to access the lock.
3. Unlock the front cover and use the back plate for the drill marks and mark the 5 drill locations.
4. Drill 5 holes.
5. Insert 5 plastic anchors (not supplied) into drilled holes.
6. The installation should be done with a flat washer (not supplied) between the head of the screw and inside back of the dispenser.
7. Insert 4 screws into the 4 corners and leave 1/8" space from the wall under head for hanging dispenser
8. Hang the dispenser on the screws through the keyhole slots at back plate.
9. Tighten the 4 screws.
10. Insert the middle anti theft screw.

Specifications

Holds up to 400 C-fold or 525 multifold towels