

1005 135 669

TOILET BOLTS WITH CAPS

Pernos para inodoro con tapas

EVERBILT

1/4 in X 2-1/4 in BOLTS
Pernos de 6.3 mm x 5.7 cm

INSTALLATION INSTRUCTIONS

Tools Needed: Adjustable Wrench, Hacksaw

1. Closet bolts slide into the slotted track on top of the closet flange.
2. Align holes in bowl with closet bolts and push nylon speed nut down to flange to hold bolt in place. Make sure wax ring is installed before installing bowl. Carefully lower bowl into place.
3. Assemble metal washer and nut to closet bolt and tighten. Break off or cut off at perforation if required.
4. Screw cap onto bolt.

