



Havelock Wool Acoustics AIR + SOUND PANELS

The Details

- High quality, all-natural wool
- Filters VOCs and other indoor air pollutants naturally
- Renewable, biodegradable, sustainable, non-toxic
- No harmful chemicals
- Reduces echo and improves acoustic comfort
- Helps regulate moisture in a space
- Wool naturally resists mold growth

Care & Maintenance

- Vacuum gently with a soft brush attachment.
- Spot clean with mild soap & water
- Avoid harsh chemicals.
- Wool naturally resists dust, odors, and moisture, no special treatments required.

Class A	125	250	500	1000	2000	NRC
1" Thick Panel	0.18	0.34	0.63	0.80	0.88	0.65
2" Thick Panel	0.23	0.49	0.93	1.01	1.01	0.85
Class D	125	250	500	1000	2000	NRC
1" Thick Panel	0.31	0.41	0.72	0.87	0.82	0.70
2" Thick Panel	0.40	0.65	0.95	0.99	0.93	0.90





WOOL AIR + SOUND PANELS INSTALLATION GUIDANCE

BEFORE YOU START

Tools & Materials Needed:

- Measuring tape
- Level
- Pencil
- Hammer
- Construction Adhesive, Finishing Nails or Eye Hooks & Wire
- Optional: screws + washers or panel mounting clips
- Utility knife (for trimming, if needed)
-

Verify Surface Compatibility:

Panels can be installed on drywall, wood, concrete, or other clean, flat interior surfaces.

Install With Adhesive

1

Prepare the surface

Ensure the wall or ceiling is clean and dry.

2

Mark wall placement

Mark your layout using a pencil & level so your panels line up. Verify spacing & orientation of panels before applying adhesive.

3

Apply adhesive

Across the back of the panel, apply 1–2" beads of construction adhesive in a zig-zag pattern. **Tip:** For ceilings or high-traffic areas, mechanical fasteners can be added for extra security.

4

Mount the panel

Position the panel on the wall along your pencil marks. Press firmly & across the entire surface to secure good adhesion. Hold in place for 10–20 seconds to allow bonding.

5

Optional fastening

For added support: Use screws with decorative washers, OR panel clips/mounts designed for acoustic panels. Space fasteners evenly along the edges or corners.

6

Final check

Ensure all panels are flush & properly adhered. Wipe away any adhesive squeeze-out immediately. Allow adhesive to fully cure per manufacturer recommendations.

Install With Finishing Nails

1

Prepare the surface

Ensure the wall or ceiling is clean and dry.

2

Position the panel

Hold the panel against the wall and use a level to ensure it's straight.

3

Secure the corners

Insert a finishing nail into each corner at a slight angle for better hold.

4

Add edge support

Place 1–2 additional nails along the edges, tapping gently until flush.

5

Check alignment

Make sure the panel is even and make small adjustments if needed.

6

Finalize placement

Lightly tap all nails to ensure they are snug without compressing the wool.

Install With Eye Hooks & Wire

1

Install eye hooks

Screw two small eye hooks into the top edge of the panel, evenly spaced.

2

Attached wire

Thread picture wire or cord through the hooks and tie securely.

3

Mark wall placement

Mark your layout using a pencil & level so your panels line up. Verify spacing & orientation of panels,

4

Install wall hooks

Install picture hooks or anchors based on wall type.

5

Hang the panel

Place the wire on the wall hooks and adjust until level.

6

Ensure a flat fit

Pull the panel gently toward the wall so it hangs flat and stable.