



STEP 1

CLEAN



STEP 2

CUT



STEP 3

PEEL & ADHERE

Tools Required:



CINCH® SEAM COVER

INSTALLATION INSTRUCTIONS:

Note: Cinch Seam Cover is intended to provide a transition between two level surfaces. Adhesive tape will need contact with a minimum of 1/4" (of the adjoining floor surfaces) for proper adhesion.

STEP 1 - CLEAN: Make sure the surface is clean, dust-free and dry. To enhance the adhesion, we recommend the surface be sealed or primed prior to placing tape on the surface.

STEP 2 - CUT: Measure and cut Cinch Seam Cover to intended length using a hacksaw.

STEP 3 - PEEL & ADHERE: Peel away the film backing from Cinch Seam Cover. Position Cinch Seam Cover above the seam. Place Seam Cover on the seam and apply firm and consistent pressure across the Cinch Seam Cover in order to properly adhere to the surface. Wait 60 minutes before walking on Cinch Seam Cover.

Note: Do not install Cinch Seam Cover below 50 degrees F.