

# INSTALLATION INSTRUCTIONS

## Tools Needed:

Pliers, Sharpshooter Spade, Light Sledge or Heavy Hammer and Hacksaw. Always wear work gloves when working with tools.



Lay out your project and measure length with string or a garden hose. Make sure to allow 8" overlap where the pieces join together. With work gloves on, snap off the stakes with pliers or a wrench. There are two stakes at each end of the edging sections. Starting at one end, put the edging loosely in the ground. Hand form each piece to conform, and partially install the stakes at the overlap connections and mid points as you go. When all the pieces are in place, drive the stakes down until they are all flush with the top of the edging. Continue pounding down until the edging is about halfway in the ground. Be sure that none of the stakes protrude above the top of the edging.

