

HOW TO INSTALL COVE or INSIDE CORNER MOULDING

Cove/Inside Corner moulding is a piece of concave trim. Cove moulding is used to finish the area where a wall meets a ceiling, or a wall meets a wall, at an inside 90 degree angle. Cove moulding can also be used to trim a mantle or shelf. It can be used in conjunction with other mouldings or trim to create compound or build-up moulding profiles.

Things You'll Need

- Molding pieces
- Miter saw
- Coping saw
- Finish Nails
- Drill

Instructions

1. Measure the length/ height of the wall meets the ceiling or wall meets wall, where you want to install the cove/inside corner.
2. Cut the cove/inside corner moulding to your measured length.
3. Drill pilot holes through the moulding, so the nails won't split the wood when installing.
4. Hold the moulding in place where the wall meets the ceiling or wall meets wall.
5. Using the finish nails, nail through the pilot holes into the wall studs, to complete installation.