



Installation

1. Remove the old wall plate from the wall outlet box.
2. If necessary, trim the cable jacket back about 2 in., being careful not to nick any wires inside.
3. If necessary, strip about ½ in. of insulation off of each wire.
4. For the phone line connections, attach the four color coded wires from the phone line cord to the corresponding color wire terminals on the back of the new wall jack. For example, connect green to green, yellow to yellow, red to red, and black to black. Retighten the screws (1) to secure the wire connections together.
5. For the Coaxial connection, connect the coaxial cable to the “F” connector (2) on the back of the new wall plate.
6. Attach the wall plate to the wall using the two screws (AA) located on the back of the wall plate.

