

Installation Guide – 10'x20' Carport Replacement Canopy Cover

Important: This guide is for the canopy cover only. The frame is not included. Please read carefully before installation.

Package Contents

- 1 × 10'x20' Canopy Cover
- 40 × Elastic Ball Bungees
- 40 × Aluminum Grommets

Tools Required

- No tools required (installation uses included elastic ball bungees).

Safety Notes

1. Install on a stable, level frame to prevent accidents.
2. Do not install during high winds or storms.
3. Keep hands clear when stretching the canopy to avoid pinching.
4. Ensure all grommets are securely fastened with bungees.

Step-by-Step Installation

Step 1 – Prepare the Frame

- Ensure your 10'x20' carport frame is fully assembled, stable, and clean.
- Confirm all frame connections are secure.

Step 2 – Position the Canopy Cover

- Unfold the canopy cover on the top of the frame.
- Align the canopy edges with the frame edges for a snug fit.

Step 3 – Attach with Bungees

- Thread an elastic ball bungee through each aluminum grommet.
- Hook the bungee over the corresponding frame tubing.
- Repeat for all grommets around the canopy perimeter.

Step 4 – Adjust and Tighten

- Ensure the canopy is evenly stretched over the frame.
- Adjust bungees as needed for a tight fit to prevent sagging or pooling of water.

Step 5 – Final Check

- Walk around the canopy and verify all grommets are secured.
- Make sure there are no loose areas or wrinkles.

Maintenance Tips

- Clean canopy with mild soap and water; avoid harsh chemicals.
- Remove snow or heavy debris promptly to prevent damage.
- Store in a dry place when not in use to extend lifespan.

Congratulations! Your canopy cover is now installed and ready for use. Enjoy protection from sun, rain, and outdoor elements.