



1. Measure the length of the wall where the wall base will be installed.
2. Cut the wall base with a miter saw, circular saw or hand saw to the necessary length.
3. Place the wallbase against the wall and test the fit.
4. Nail the quarter round into the wall with finishing nails.
5. Fill nail holes with coordinating putty.
6. Use quarter round to cover the flooring expansion gap at the wall base, if necessary or preferred.