

## 4 WAY FLAT, 12"

### INSTALLATION INSTRUCTIONS INSTRUCCIONES DE INSTALACION CONSIGNES D' INSTALLATION

#### READ ALL WARNINGS AND INSTRUCTIONS BEFORE INSTALLATION

**WARNING:** CONSULT VEHICLE AND TRAILER OWNER'S MANUAL BEFORE INSTALLATION. CHECK FOR SENSORS, WIRES, OR COMPONENTS BEHIND THE MOUNTING SURFACE PRIOR TO INSTALLATION.

#### INSTALLATION INSTRUCTIONS

1. DISCONNECT VEHICLE POWER SUPPLY
2. SELECT THE APPROPRIATE MOLDED CONNECTOR REQUIRED FOR THE INSTALLATION. THE 4-WAY CONNECTOR WITH THREE EXPOSED METAL PRONGS SHOULD TERMINATE FROM THE TRAILER. THE 4-WAY CONNECTOR WITH ONE EXPOSED METAL PRONG SHOULD TERMINATE FROM THE VEHICLE.
3. CONNECT THE WIRE LEADS TO THE PROPER CIRCUITS. FOR PROPER LIGHT FUNCTION A GROUND CONNECTION MUST BE ACHIEVED.
  - GREEN WIRE – RIGHT TURN AND BRAKE LIGHT**
  - YELLOW WIRE – LEFT TURN AND BRAKE LIGHT**
  - BROWN WIRE – TAILLIGHTS**
  - WHITE WIRE – GROUND**
4. SECURE ANY EXCESS WIRE.
5. RECONNECT VEHICLE POWER SUPPLY.
6. TEST LIGHTS.

#### LEA TODAS LAS ADVERTENCIAS E INSTRUCCIONES ANTES DE LA INSTALACIÓN

**ADVERTENCIA:** CONSULTE EL MANUAL DEL PROPIETARIO DEL VEHÍCULO Y DEL REMOLQUE ANTES DE LA INSTALACIÓN. VERIFIQUE SI HAY SENSORES, CABLES O COMPONENTES DETRÁS DE LA SUPERFICIE DE MONTAJE ANTES DE LA INSTALACIÓN.

#### INSTRUCCIONES DE INSTALACIÓN

1. DESCONECTE LA FUENTE DE ALIMENTACIÓN DEL VEHÍCULO.
2. ELIJA EL CONECTOR MOLDEADO QUE SE REQUIERE PARA LA INSTALACIÓN. EL CONECTOR DE 4 VÍAS CON TRES PUNTAS METÁLICAS EXPUESTAS DEBERÁ ENLAZARSE DESDE EL REMOLQUE. EL CONECTOR DE 4 VÍAS CON UNA PUNTA METÁLICA EXPUESTA DEBERÁ ENLAZARSE DESDE EL VEHÍCULO.
3. CONECTE LAS TERMINALES DE ALAMBRE A LOS CIRCUITOS ADECUADOS. PARA UNA FUNCIÓN DE ILUMINACIÓN ADECUADA DEBE HABER UNA BUENA CONEXIÓN A TIERRA.
  - ALAMBRE VERDE - VUELTA A LA DERECHA Y LUZ DE FRENOS**
  - ALAMBRE AMARILLO – VUELTA A LA IZQUIERDA Y LUZ DE FRENOS**
  - ALAMBRE CAFÉ - LUCES TRASERAS**
  - ALAMBRE BLANCO - TIERRA**
4. ASEGURE CUALQUIER SOBRANTE DE ALAMBRE.
5. VUELVA A CONECTAR LA FUENTE DE ALIMENTACIÓN DEL VEHÍCULO.
6. PRUEBE LAS LUCES.

#### LISEZ TOUS LES AVERTISSEMENTS ET TOUTES LES INSTRUCTIONS AVANT L'INSTALLATION.

**AVERTISSEMENT:** CONSULTEZ LE MANUEL DU PROPRIÉTAIRE DU VÉHICULE ET DE LA REMORQUE AVANT L'INSTALLATION. VEILLEZ À CHERCHER LES CAPTEURS, LES CÂBLES OU LES COMPOSANTS DERRIÈRE LA SURFACE DE MONTAGE AVANT L'INSTALLATION.

#### INSTRUCTIONS POUR L'INSTALLATION

1. DÉBRANCHEZ L'ALIMENTATION ÉLECTRIQUE DU VÉHICULE
2. CHOISISSEZ LE CONNECTEUR MOULÉ APPROPRIÉ REQUIS POUR L'INSTALLATION. LE CONNECTEUR À 4 VOIES AVEC TROIS BROCHES MÉTALLIQUES EXPOSÉES DOIT ÊTRE RACCORDÉ À PARTIR DE LA REMORQUE. LE CONNECTEUR À 4 VOIES AVEC UNE BROCHE MÉTALLIQUE EXPOSÉE DOIT ÊTRE RACCORDÉ À PARTIR DU VÉHICULE.
3. CONNECTEZ LES FILS CONDUCTEURS AUX CIRCUITS APPROPRIÉS. UNE CONNEXION À LA TERRE EST REQUISE POUR QUE LES FEUX FONCTIONNENT CORRECTEMENT.
  - FIL VERT – FEU DE VIRAGE À DROITE ET DE FREINAGE**
  - FIL JAUNE – FEU DE VIRAGE À GAUCHE ET DE FREINAGE**
  - FIL BRUN – FEUX ARRIÈRE**
  - FIL BLANC – TERRE**
4. FIXEZ TOUT EXCÉDENT DE FIL.
5. REBRANCHEZ L'ALIMENTATION ÉLECTRIQUE DU VÉHICULE.
6. VÉRIFIEZ LE FONCTIONNEMENT DES FEUX.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR TOWSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9215 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT [WWW.TOWSMART.COM](http://WWW.TOWSMART.COM).



Winston Products Company  
towsmart.com  
WINSTON PRODUCTS, LLC.  
30339 Diamond Parkway  
Cleveland, OH 44139