



REQUIRED TOOLS:

Ruler, Pencil, #2 Phillips Screwdriver, Drill, 5/64" drill bit

INSTALLATION INSTRUCTIONS:

1. Hold the center of the plate 45" from the bottom edge of the door, and the edge of the plate 1" from the vertical edge of the door.
2. Mark the hole locations of the plate onto the door.
3. Drill 5/64" pilot holes into each marked location, with each hole about 3/4" deep.
4. Secure plate to door with provided screws.