

ORNAMENTAL

— DECORATIVE MILLWORK —

A NOVO Building Products Company

ACCENT WALL BOARD INSTALLATION INSTRUCTIONS

YOU WILL NEED:

Construction adhesive
Fine sand paper
Measuring tape
Level
Fine Tooth Saw
Hammer or Nail Gun
Finishing Nails

INSTRUCTIONS:

1. Acclimate boards to room environment for 24 hrs prior to start.
2. Finish/Seal all non-primed boards front, back and edges.
3. Assure that installation surface is smooth, clean and dry. If the walls are flat and in good condition, the boards may be glued and nailed directly to the wall. For uneven or damaged walls, 1x2 or 1x3 furring strips should be used. For vertical applications, install furring strips horizontally at top and bottom of wall and spaced 16" or 24" on-center between. For horizontal and diagonal applications, install furring strips vertically at each edge and spaced 16" on-center between. Boards can then be glued and nailed to the strips.
4. Measure and cut boards to length.
5. Install the first board using a level to assure board is level. (NOTE: if installing flush to adjoining surface, the board may need to be scribed and planed for good fit)
6. Continue installing boards, leveling each as installed. Trim as necessary.