



PREMIER
COPPER PRODUCTS

HAND HAMMERED COPPER TILES

INSTALLATION INSTRUCTIONS

Use regular Mastic to install our copper tiles. Do not use grout only to install the tiles.

Use a heavy trail of Mastic to ensure the adhesive sticks to all areas on the back of the copper tile.

Use a non-sanded grout for the trim.

Please contact us with any installation questions.