

Assembly Instruction:

Step 1: Two parts as below



Step 2: Insert small stick into the round end of large stick. Then insert sharp end of large stick into underground.

