

## 1. PREP



**PREP:** Push in damaged or rough edges to the inside of the wall and sand drywall damage smooth using sandpaper. Make sure the area to be repaired is clean, dry, firmed and free of any loose debris or materials.

## 2. PEEL



**PEEL:** Using the easy-to-remove slit, remove the patch from the back, white carrier sheet (like removing a sticker) exposing the entire adhesive surface of the patch.

## 3. PLACE



**PLACE:** Position the gray center circle of the patch over the center of the damage and smooth the patch to the surrounding drywall using your hand. (Only press where the patch is in contact with the drywall. **DO NOT** push through the damaged area and do not pull the pop-up tab until after the first coat of paint.)

## 4. PAINT



**PAINT:** Paint immediately using a high-quality paint roller.  
**NO SPACKLING OR SANDING NECESSARY.**

## 5. REMOVE



**REMOVE:** After first coat of paint is applied and surrounding drywall is dry, remove clear protective layer by pulling the pop-up tab.

## 6. FINISH



**FINISH:** Apply two additional coats of paint for a smooth and invisible repair. (Eclipse<sup>TM</sup> can also be used on textured walls & ceilings and will accept aerosol spray textures or textured paint rollers)

**FOR BEST RESULTS:** Make sure to follow the preparation instructions prior to completing the repair. After removing the protective layer, apply two additional coats of paint. Using a primer coat will increase paint adhesion and improve dry time. Do not apply when temperatures are below 40°F. Not for exterior use or on wet or damp surfaces.

**FINISH PROJECT FASTER**

Paint immediately & finish in minutes

1



PATCH

2



PAINT

3



SUPERIOR  
FINISH

**4X STRONGER**  
**THAN DRYWALL ITSELF**  
Superior impact resistance